



INSTRUCTIONS FOR STERILIZATION OF THE MEMBRANES WITH OUR ST2 CARTRIDGE

1. Close the sea water inlet valve.
2. Open the sterilizing cartridge
3. Remove the top grid
4. Place the foam filter at the bottom of the filter
5. Pour the powder into the cartridge
6. Replace the top grid and close the cartridge
7. Check that the seal is properly positioned.
8. Remove the 5µm cartridge from the pre-filter.

Remove the 5µm
cartridge from the
pre-filter



Remove the 5µm
cartridge from the
2nd pre-filter



9. Replace with the sterilizing cartridge

Replace the 5µm
cartridge with the
sterilizing
cartridge ST2



Replace the 5µm
cartridge (in the **2nd pre-filter**) with the
sterilizing cartridge.



10. Set the rinsing valve to pressurized fresh water and leave a little sterilizer in the filter.
11. Do not run the desalinator at this point.
12. The sterilization remains effective for six months at most. (Repeat after this time as necessary).

IMPORTANT:

Before next use, rinse the desalinator thoroughly with fresh water for 15 minutes. Ensure that the sterilizing cartridge has been removed and replaced by a 5 µm cartridge.

BEWARE:

The ST2 cartridge is reusable.