


Watermaker off:

1. Close the sea water inlet valve.
2. Open the sterilizing cartridge
3. Remove the top grid
4. Place the foam filter at the bottom of the filter
5. Pour the powder into the cartridge
6. Replace the top grid and close the cartridge
7. Check that the seal is properly positioned.
8. Remove the 5µm cartridge from the pre-filter.

For the 12, 24V et DUO models :
 Remove the 5µm cartridge from the pre-filter



For the 230 et 400V models :
 Remove the 5µm cartridge from the **2nd** pre-filter



9. Replace with the sterilizing cartridge

For the 12, 24V et DUO models :
 Replace the 5µm cartridge with the sterilizing cartridge ST2



For the 230 et 400V models :
 Replace the 5µm cartridge (in the **2nd** pre-filter) with the sterilizing cartridge



10. Set the rinsing valve to pressurized fresh water and leave a little sterilizer in the filter.
11. Do not run the desalinator at this point.
12. The sterilization remains effective for six months at most. (Repeat after this time as necessary).

IMPORTANT: Before next use, rinse the desalinator thoroughly with fresh water for 15 minutes. Ensure that the sterilizing cartridge has been removed and replaced by a 5 µm cartridge.

BEWARE : The ST2 cartridge is reusable.



WARNING: This product is harmful. Thank you to use mask and gloves when you manipulate